













**Betriebsanleitung**  
**Operating Instructions**  
**Instructions de service**  
**Istruzioni d'uso**  
**Handleiding**  
**Instrucciones para el manejo**  
**Manual de instruções**  
**Naudojimosi instrukcija**  
**Kasutusjuhend**  
**Lietošanas instrukcija**  
**Οδηγίες χρήσης**  
**取扱説明書**  
**사용설명서**







**Driftsinstruks**  
**Driftsinstruktioner**  
**Käyttöohje**  
**Driftsvejledning**  
**Instrukcja obsługi**  
**Kezelési útmutató**  
**Návod k obsluze**  
**Navodilo za uporabo**  
**Návod na obsluhu**  
**EI Kitabi**  
**Инструкция по эксплуатации**  
**使用说明书**

**DT 4.4**







2006/42/EG









 			 <p><b>MAX. PRESSURE</b></p>	
				 <p><b>MAX.</b></p>
 <p><b>AIR</b></p>			<p>DIN EN ISO 3744</p>	<p> <math>L_{pA} = 60 \text{ dB(A)} - 50\text{Hz}</math>  <math>L_{pA} = 60,5 \text{ dB(A)} - 60\text{Hz}</math>  <math>K_{pA} = 3 \text{ dB(A)}</math> </p>
				

	<p> <math>A &gt; 100\text{mm}</math>  <math>A &gt; 4"</math> </p>	<p> <math>&gt; 5^\circ\text{C}/41^\circ\text{F}</math>  <math>&lt; 45^\circ\text{C}/113^\circ\text{F}</math> </p>	<p>    max. 90% </p>	<p>    max. 800m </p>
<p><b>1</b></p>  <p>    7 kg  15,4 lbs </p>	<p><b>2</b></p> 			

28100027101 05/11





<p>D: 25 mm H: 24 mm No.: 909580</p>		

**E.**

<b>3000 h</b>	
	<p><math>A_{MIN} &gt; 11mm</math> <math>A_{MIN} &lt; 11mm</math></p>
<p>DT 4.4 → No. 90138700005 (SET)</p>	

**F.**


**G.**

<b>500 h</b>		
<p>1~ (DT 4.4 EW)</p>		

**H.**

<p><a href="http://www.becker-international.com">www.becker-international.com</a></p>	

**BECKER**

Gebr. Becker GmbH  
Hölker Feld 29-31  
D-42279 Wuppertal  
[info@becker-international.com](mailto:info@becker-international.com)

---

**SERVICE**  
[www.becker-international.com](http://www.becker-international.com)  
Sales and service network